

The Extreme Bed Frame

AMERICA'S PREMIUM BED FRAME

THE STRONGEST BED FRAME EVER MADE

QUICK-CLICK ASSEMBLY INSTRUCTIONS

~~PARTS INCLUDED~~

2 SIDE RAILS (2 LEGS ATTACHED TO EACH)
2 CROSS RAILS (1 LEG ATTACHED TO EACH)
2 CENTER RAILS (NO CENTER RAILS ON TWIN)

6 LEG INSERTS (4 ON TWIN)
6 CASTERS or METAL GLIDES (4 ON TWIN)
2 'L'-SHAPED END CAPS


STEP 1

Lay the two long side rails on the floor with the headboard bracket of each rail pointing toward the head of the bed.

With the leg in the middle of the cross rail positioned toward the inside of the frame, insert the end of the cross rail into the slot in the top of the leg attached to the right side rail.

With one hand, hold the side rail so the attached leg is vertical. With the other hand, push straight down on the cross rail until it engages the plastic locking cap.

Repeat with the other cross rail.



STEP 2


Place an insert in each of the legs, followed by the casters or glides.

Slide an 'L'-shaped end cap over the ends of the side rails.

STEP 3 *** SKIP ON TWIN SIZE ***

After the bed frame has been attached to the headboard, insert the end of the two center rails into the slots in the legs attached to the cross rails, and push straight down.

NOTE: CENTER RAILS DO NOT LOCK INTO PLACE.



TO DISASSEMBLE THE BED FRAME

Lift out the center rails.

Pull outward and up on the bottom of the plastic locking cap, and lift out the cross rail.

